ACCURATE • AVAILABLE • RESPONSIVE • QUICK

Operating instructions for the Programmable Dispenser

Set Clock

Press MODE button until clock appears in the bottom right hand corner. Then press the HOUR and MINUTE buttons until the current time appears. Keep in mind that this is a 24-hour clock. Then press the WEEK button to set the day of the week until the desired day appears.

- 1: Monday
- 2: Tuesday
- 3: Wednesday
- 4: Thursday
- 5: Friday
- 6: Saturday
- 7: Sunday

Set On / Off Time

The unit will operate 24 hours a day unless programmed differently. Press MODE button until start appears, then press HOUR and MINUTE until the desired start time is on the display. Repeat this procedure for the STOP function, to set the desired stop time.

Set Spray Interval

The unit is preset at a 15-minute spray interval. All other intervals must be programmed. Press MODE button until INTERVAL appears. Then press MINUTE button until the desired spray interval appears. Choose spray intervals from 1, up to 60 minutes.

Set Weekend On / Off

Press MODE button until WEEK appears. Press WEEK button to set weekend on or off on display indicating Monday - Friday operation.

Place Can in Dispenser

Make sure tip is facing forward. Shoulder of can should be resting on retainer bracket. Reset by pressing the ON / OFF each time you change batteries or replace cans.

Activate Unit

Press the ON / OFF button. The led indicator will flash green / red 3 times and the activated arm will activate 1 time as a system check.







